

QUICK CONNECT GUIDE

Guide D'Installation Rapide | Guía De Conexión Rápida

STOP

DO NOT RETURN THIS TV TO THE STORE!

SHOULD YOU HAVE A PROBLEM

please call Westinghouse Customer Service at 1-800-701-0680 or go to www.westinghouseelectronics.com/support/

IMPORTANT REMINDERS:

Register your product(s) and ensure that you will have access to firmware upgrades, receive product updates and special offers.


REGISTER TODAY AT:

<http://westinghouseelectronics.com/support/productreg/>

IF CONNECTING TO CABLE

Si se relia a un Cable | Si conecta con un Cable


⚠ No need to do Channel Scan. Press input and select HDMI.



IF CONNECTING TO A SATELLITE


Si se relia a una Satellite | Si conecta con una Satélite

⚠ No need to do Channel Scan. Press input and select HDMI.




IF CONNECTING TO DVD/BLURAY

Si se relia a un DVD/BluRay | Si conecta con un DVD/BluRay



IF CONNECTING TO AN ANTENNA

Si se relia a una Antena | Si conecta con una Antena



For tuner activation and channel scan refer to User Manual

Pour le tuner le balayage d'activation et de canal se rapportent au manuel d'utilisation.
Para el sintonizador la exploración de la activación y del canal refiere al manual del usuario.